

7 INCH TFT LCD DOPPLER SPEED LOG

OPERATION MANUAL

Model: DS99



NINGLU

Doc No: NLT-DS99-SEN

Version: V170704

Safety instructions

WARNING	CAUTION
 ELECTRICAL SHOCK HAZARD! Do not open the equipment. Only qualified personnel should work inside the equipment.	Please follow the guide in page 31 to replace the fuse.
Immediately turn off the power if water leaks into the equipment or an object is dropped into the equipment. Continued use of the equipment can cause fire or electrical shock. Contact NINGU for service	Do not use chemical cleaners such as alcohol, acetone and benzene to clean the equipment. Chemical cleaners can remove paint and markings. Use only a soft, dry cloth.
Keep the equipment away from flammable liquids and heater. A heater can melt the equipment's power cord, which can cause fire or electrical shock.	Do not power the equipment when the transducer is in air. The transducer may become damaged.
Do not operate equipment with wet hands. Electrical shock can result.	Handle all units carefully. Damage can lead to corrosion.
Do not paint the transducer face. Handle the transducer with care. Paint will affect equipment performance..	When dry docked remove marine life from the transducer. Remove marine life to maintain good sensitivity.

Content

Foreword	1
Conditions affecting the accuracy	1
System	2
System diagram	2
System overview	3
Specifications	4
Environment	4
Performance index	4
Operation	6
Fixed keys	6
POWER	6
BRIGHTNESS	6
MENU	6
OK	6
DAY/NIGHT	6
RESET	6
Arrows (UP▲/DOWN▼/LEFT▶ / RIGHT◀)	6
Menu	7
Display interface	7
Menu items	7
Mode	8
Language	8
Speed Avg.	8
Speed Unit	8

Trip. Unit	8
Speed Off. (speed calibration)	8
XDR Offset (direction calibration)	9
Debug Mode.....	9
Debug Spd	9
Track DPT	10
Default.....	10
Output & Input	11
GPS input--VTG	11
Speed log data output---VBW	11
Speed log data output --- VLW	12
Relay output (switch quantity) output	12
Installation	13
Displayer installation	13
Controller/Transceiver Installation	14
Transducer installation	15
Installation position	15
Watertight test.....	16
Tank installation	17
Gate valve installation	18
Gate valve replacement	19
System wiring	29
Internal wiring	29
DS991 displayer backboard diagram	29
External wiring	30

DS992 controller terminal diagram	30
Trouble shooting	31
Common fault.....	31
Fuse replacement	31
IR861 speed&distance repeater.....	32
IR861 operation	32
IR861 accepted messages NMEA0183.....	33
IR861 wiring.....	33
Environmental according to IEC60945.....	33
IR861 installation	34

Foreword

DS99 displays ship's speed relative to water (Fore/ Aft) and distance (Trip/ Total) in 7 inch TFT LCD, using Doppler principle.

Applying new technology of high integration and stability, DS99 provides you the optimum choice for large ship. Its rugged and modern design offers excellent user feelings.

Your Doppler speed log will perform to the utmost of its ability only if it is operated and maintained in accordance with the correct procedures.

Conditions affecting the accuracy


The DS99 measures ships speed by detecting the doppler frequency shifts of the echo reflected by a watermass (water layer containing plankton and other micro- organisms) located within the measuring area, which is usually about 2 m. In some instances, however, no signal is returned because of too little plankton in the sensing depths. This phenomenon can occur in particular areas in particular seasons. The probable cause is the plankton are lying in deep water because an ice-melted cold water mass covers the sea surface. Similar cases may also occur in a freshwater lake.

The detecting accuracy will be affected by the following factors:

- Rough weather (may be sea state 6 or severer)
- Improper location of transducer
e.g., too close to the propeller, thrusters, drain tubes, echo sounder transducer
- Depth under the keel if less than 3 m
- Water temperature/ salinity (sound velocity)
- Roll $>\pm 10^{\circ}$

System

System diagram



System overview

Displayer:

Model: **DS991 (IP23)**
Function: ship's speed and distance (trip & total) display
system operation and control
Dimensions: 188(W) × 166(H) × 65(D)
Installationsite: navigation bridge

Controller:

Model: **DS992 (IP23)**
Function: signal receiving/calculation from transceiver/external equipments
speed and distance signal output to displayer/external equipments
Dimensions: 350(W) × 300(H) × 128(D)
Installationsite: navigation bridge

Transceiver:

Model: **DS993 (IP56)**
Function: transforming transducer ultrasonic signal to speed signal
Dimensions: 350(W) × 300(H) × 128(D) (stainless steel)
Installationsite: 20 meters away from transducer

Transducer:

Model: **DS994 (IP68)**
Function: transmitting/receiving ultrasonic wave
Installationsite: ship bottom

Tank:

Model: **DS996**
Function: transducer replacement on dry dock

Gate valve:

Model: **DS997**
Function: transducer replacement in water

Specifications

Environment

Working temperature: -15~+55℃, complying to IEC60945

Working humidity: 40±3℃; 93%± 2% relative humidity

Working depth: water depth under the keel >3m

Protection:

Items	Protection
Displayer	IP23
Controller	IP23
Transceiver	IP56
Transducer	IP68

Roll/pitch: roll ±10°, pitch ±5°, DS99 can normally work.

Safe distance of Magnetic Compass: >132cm

Performance index

Power supply: AC110/ 220V 50/60Hz

Working frequency: 1MHz

Speed display:

Numerical display: **.*, Step: 0.1kn

Speed range: Fore-Aft: -10.0~+40.0kn(-18.4~+73.6km/h)

Speed accuracy: 2% or 0.2kn whichever is the greater

Accuracy is subject to shallow water effects, to the effect of wind, current and tide, and sensor location. Any ultrasonic equipment having the same frequency may interfere with speed measurement. The Doppler Log transducer should be installed apart from the transducers of such kind of equipment.

▲**.*/kn (+40.0kn/ 73.6 km/h max.)

Aft: ▼**.*/kn (-10.0kn/ -18.4 km/h max.)

Analog speed: 0~30kn/ 0~60km/h

Distance display:

Numerical display: ****.**, Step 0.01NM

Trip distance (reset)/ Total distance

Trip range: 0.00~9999.99 NM (km)

Total range: 0.00~999999.99 NM

Distance accuracy: 2% or 0.2NM whichever is the greater

Accuracy is subject to shallow water effects, to the effect of wind, current and tide, and sensor location. Any ultrasonic equipment having the same frequency may interfere with speed measurement. The Doppler Log transducer should be installed apart from the transducers of such kind of equipment.

LCD display:

Users can clearly read the speed/ distance within 2 meters distance.

Input/ Output:

	Equipments	Interface	Format
Input	GPS	J6	NMEA0183 data(VTG)
Output	ECDIS VDR Repeaters Radar	J4/J5	NMEA0183 data(VBW)
			NMEA0183 data(VLW)
Output	BNWAS Radar	J7/J8/J9	Relay output (switch quantity) Load: DC30V 2A; AC125V 0.5A

Operation

Fixed keys



POWER

Turn on/off the system.

Press **【POWER】** key more than 3 seconds to turn off the system.

BRIGHTNESS

Adjust the LCD brightness (9 optional levels).

MENU

Turn on the menu.

OK

Save the setting and quit from the menu.

DAY/NIGHT

Switch between day display mode and night display mode.

RESET


Reset trip distance to “0”.

Arrows (UP ▲ / DOWN ▼ / LEFT ► / RIGHT ◀)

UP ▲ / DOWN ▼ : select MENU item; LEFT ► / RIGHT ◀ : value setting.

Menu

Display interface



Menu items

Note: In the following MENU list, the factory setting is marked with grey back color, such as **DPL**.

Menu	Parameter setting	Note (Default)
Mode	[AUTO DPL GPS]	
Language	[中文 English]	Set operation language
Speed Avg.	[1s 15s 30s]	Select time period calculating the average speed.
Speed Unit	[kn km/h]	kn(knot)
Trip. Unit	[NM km]	NM: nautical mile, km: kilometer
Speed Off.	[+0.0%]	-29.9~+29.9%
XDR Offset	[+0°]	-45~+45°
Debug Mode	[ON OFF]	Check the signal output
Debug Spd	[+10.0kn]	+0~+39.9kn
Track DPT	[2.0m]	1.0~3.0m
Default	[ON OFF]	"ON": restore to factory settings

Mode

When the DS99 fails, the display unit can be used as a monitor display tool for GPS speed.

【AUTO】 indicates Doppler speed, but if the DS99 fails, a GPS speed will be indicated. “AUTO” shows on the on the screen.

When DS99 displays GPS speed, it will not output any data.

【DPL】 indicates Doppler speed, and “STW” shows on the screen.

【GPS】 indicates GPS speed, “GPS” shows on the screen.

Set Mode in Menu 【 AUTO DLP GPS 】.

Language

Set the Language in Menu 【 中文 English 】.

Speed Avg.

Select time period calculating the average speed.

Set the Speed Avg. in Menu 【1s 15s 30s】.

Speed Unit

Set the Speed Unit in Menu 【kn km/h】.

Trip. Unit

Set the Trip. Unit (distance) in Menu 【NM km】.


Speed Off. (speed calibration)

Compare the speed with the standard speed to calibrate.

Set Speed Off. In Menu 【-29.9~+29.9%】 , default: +0.0%.

This value should be confirmed during calibration and not be modified in usual use.

XDR Offset (direction calibration)



During transducer installation,
make sure direction angle (X)
is less than 5° !

During installation, transducer diameter line through the transducer hump should on the center fore-aft line of the ship. If not, the direction need to be calibrated as showed on the left picture. c-a=GPS speed , and ”

During transducer installation, make sure direction angle(X) is less than 5° .

Set XDR Offset In Menu **【 $-45^\circ \sim +45^\circ$ 】**, default: **+0°**.

This value should be confirmed during calibration and not be modified in usual use.

Debug Mode

The DS99 system simulates to be operating and outputting analog signals to external equipments. In Debug mode, the screen will show “Debug”.

Debug Spd

Set the analog speed of Debug mode.

Set Debug spd in Menu **【 $+0 \sim +40kn$ 】** , default : **+10.0kn**.

Track DPT

When speed showed is unsteady due to underwater bubbles etc, users can adjust this value to steady the speed.

Set Track DPT in Menu 【1.0~3.0m】 , default: 2.0m.

Default

“ON”: restore to factory setting.

Please caution! If restore to factory settings, all menu settings will be back to default value.

Output & Input

GPS input--VTG

The actual course and speed relative to the ground.

\$ --VTG,x.x,T,x.x,M,x.x,N,X.X,K,a*hh<CR><LF>
 1 2 3 4 5 6

1. Course over ground, 000 - 359, T= degrees true
2. Course over ground, 000 - 359, M= degrees magnetic
3. Horizontal speed over ground, 0.00, N=Knots
4. Horizontal speed over ground, 0.00, K=km/h
5. Mode indicator, A= Autonomous
 D= Differential
 E= Estimated (course reckoning) mode
 M= Manual input
 S= Simulator
 N= Data invalid

The positioning system Mode indicator field shall not be a null field.

6. Checksum

Speed log data output---VBW

Water-referenced and ground-referenced speed data format

\$ --VBW,x.x,x.x,A,x.x,x.x,A,x.x,A,x.x,A*hh<CR><LF>
 1 2 3 4 5 6 7 8 9 10 11

1. Longitudinal water speed, Knots
2. Transverse water speed, Knots
3. Status: water speed, A=data valid V=data invalid
4. Longitudinal ground speed, Knots
5. Transverse ground speed, Knots

6. Status: ground speed, A=data valid V=data invalid
7. Stern transverse water speed, Knots
8. Status: stern water speed, A=data valid V=data invalid
9. Stern transverse ground speed, Knots
10. Status: stern ground speed, A=data valid V=data invalid
11. Checksum

Speed log data output --- VLW

The distance travelled, relative to the water.

\$ --VLW, X.X, N, X.X, N, X.X, N , X.X, N *hh<CR><LF>
 1 2 3 4 5

1. Total cumulative water distance, NM
2. Water distance since reset, NM
3. Total cumulative ground distance, NM
4. Ground distance since reset, NM
5. Checksum

Relay output (switch quantity) output

DS99 outputs speed signals of relay output (switch quantity) (200P) once to external equipment every 0.005NM.

DS99 outputs power-fail alarm signals of relay output (switch quantity) to BNWAS.

When DS99 works normally, contact closure.


When DS99 drops power, contact open.

Note: NMEA0183 format: IEC61162-1: Edition4.0 2010-11, baud bit is 4800, 8data bits, with checksum.

Installation

Displayer installation


Hand/flush installation



ATTENTION!

- Avoid direct sunlight, shock and vibration.
- Do not place the display near the exhaust pipes or vents.
- Operator unit should be far away from the equipment which generate electromagnetic radiation, such as: motors, generators.
- Displayer should be located in mild environment of steady temperature and humidity.
- Make sure enough maintain space of the displayer back and side.

Controller/Transceiver Installation




ATTENTION!

- Transceiver should be installed in ventilated and dry area and not be covered with any objects.
- Make sure enough maintain space of the displayer back and side.
- Controller and transceiver's distance with magnetic compass should be more than 132cm to avoid electromagnetic interference.
- **To the utmost of ability, make sure the cable between controller and transceiver is less than 150 meter.**

Transducer installation

Installation position



It's best to mount the transducer in the fore part of the ship, in the center fore-aft line of the ship, or as close to the centerline as possible. Max distance: 0.5m. Max angle: 5° .

Optimal system operation is achieved by fitting the transducer as deep as possible on the hull.

Transducer should be away from echo sounder transducer at least 2.5m.

The transmitting surface of the transducer must be installed horizontal (parallel to ship's horizontal plane).

Do not mount transducers close to the bow thruster propeller outlets, or aft of other hull installations (outlets, vents or other protruding details).

It is necessary to select a part of the hull that is submerged under all load and speed conditions, and to avoid positions where air is trapped in heavy weather.

If a flat, horizontal section is not available for transducer fitting, the shipyard must construct a suitable bed. Welding seams in this area should be smoothed and rounded off, in order not to create turbulence or aeration at speed.

Protect the active element of the transducer during transport and installation, and do not paint the surface. *Because the transducer surface has already been painted with special anti-sea organism coating in factory, so please do not clean the surface with alcohol and other cleaning agents*

Transducers are delivered with a fixed cable, and this cable should not be extended by connecting to any new cables.


Watertight test

When transducer installation finished, watertight test will be done.

After watertight test, please take the transducer out and close the valve.

Amount the transducer again before the ship launching.

Tank installation




Note, the hole dimension is suggested to $\phi 130\text{mm}$

The gap must be in front of the bow and in parallel to the keel line.

Gate valve installation

The gate valve should be placed in a dry place, large enough for installation and disassembly of gate valve and transducer.




Gate valve replacement

Installation Space Necessary

Ensure enough operation space and lighting before installation.


Exit passageway should comply with relevant standard.



Installation Step 1: Bottom flange welding

Disassemble the bottom flange (without PTFE gasket) from gate valve.
ATTENTION!

PTFE gasket must be taken off from the bottom flange to avoid heat distortion.




Standard welding practice and procedures should be observed.


Installation Step 2: Ball valve welding

When bottom flange has cooled off, remember put PTFE gasket on the top of bottom flange, then mount the ball valve.


The gate valve will not be waterproof without the PTFE gasket!



Ball valve open/close status




Fully open




Totally closed

Installation Step 3: Transducer installation




Transducer assembly




Installation Step 4: Top flange installation

Use hexagon screws to tighten the top flange with ball valve.



Flange assembly




Installation finished

Note: If the two nuts are still tighten, the screw nut cannot be not directly rotated by using a wrench alone and the flat slot of the sliding tube must be hold with another wrench at the same time. The slide tube cannot be rotated to avoid the damage of the transducer.


When the ship is afloat, the big sealing nut only can be unscrewed a little that allow the extention tube can be up and down.

Insert the extention tube to the bottom flange, turn the tube until the transducer is flush with the lower surface of the bottom flange. At this time, the big sealing nut is a little higher than mark line on the extention tube.

Tighten the big sealing screw.



Transducer removal




- 1 Unscrew the big sealing nut carefully until the extension tube can be lift and little water trickles out.

Then lift the extension tube.

- 2 Close the valve completely.
- 3 Disassemble the top flange and remove the transducer.

System wiring

Internal wiring




To ensure the optimum working performance, please do not extend the cable between DS994 transducer (transducer cable) and DS993 transceiver. The cables connecting DS993 transceiver and DS992 controller should not be longer than 150m.

DS991 displayer backboard diagram


Data input/ output

To DS992 J2




Power

To DS992 J1




External wiring



ALARM relay output: speed log works normally, contact closure;
speed log power off, contact open.

DS992 controller terminal diagram



Trouble shooting


Do not disassemble the equipment when fails.

Please contact with NINGLU after-service department.

Common fault

Symptom	Cause	Remedy
Cannot turn on the power	Loosened power cable Blown fuse	Fasten the power cable Replace the fuse
Power is on but nothing spears on the screen	LCD brilliancy too low	Press 【  】 key several times
Speed display: “**.*”		Error in data
Speed display: “--.-”		No data input

Fuse replacement



Controller DS992:

Cabinet internal: Overall fuse specification: 250V 2A 5×20mm.


Cabinet internal: 1 black cylinders at “FS2”.

Unscrew the head to find the fuse inside: 250V 1A 5×20mm.

Transceiver DS993:

Cabinet internal: 1 black cylinder at “F200”.

Unscrew the head to find the fuse inside: 250V 2A 5×20mm.



IR861 speed&distance repeater

IR861, dual axis speed and distance repeater and her longitudinal ships speed information. IR861 also speed log having NMEA0183 output. (IR861 is c

IR861 operation

First line: FORE (↑) --- AFT (↓) speed

Second line: PORT (←) ---STBD(→)

speed

Third line: Distance

Press **TRIP/ TOTL** key to switch between trip distance and total distance.

Press **WT/BT** key to switch between ground speed and water speed.

Press **UP▲ / DOWN▼** keys to adjust brightness.



Diagnostic information

- If IR861 does not receive any signal from the external source for more than 3 seconds Error ("Err") message is indicated on the LEDs. This may happen, for example if external talker is not connected or connection polarity is not correct.
- If input messages do not contain sentences, required for indication of selected data, "_" (underline symbol) is indicated on the corresponding LEDs. As an example: if there is no VLW message available on the input, IR861 will indicate "_____" instead if distance counter
- If fields in the received message is empty (not valid data), dots are indicated on the corresponding LEDs. As an example, if speeds over ground fields are empty in VTG or VBW sentences and BT mode is selected on IR861, "..." will be indicated instead of speed value.

IR861 accepted messages NMEA0183

VBW - Dual Ground/Water Speed.

\$--VBW,x.x,x.x,A,x.x,x.x,A,x.x,A,x.xA*hh<CR><LF>

VTG - Course Over Ground and Ground speed

\$--VTG,x.x,T,x.x,M,x.x,N,x.x,K,a*hh<CR><LF>

Note: Fields, containing course information (underlined>) are not processed

Note: km/hour field is not processed

VHW - Water speed and heading

\$--VHW,x.x,T,x.x,M,x.x,N,x.x,K,*hh<CR><LF>

Note: fields, containing heading information (underlined>) are not processed

Note: km/hour field is not processed

VLW - Distance Traveled through the Water

\$--VLW,x.x,N,x.x,N,x.x,N,x.x,N*hh<CR><LF>

IR861 wiring

WIRING CONNECTING				Color	Signal	Color	Signal
COLOUR	SIGNAL	COLOUR	SIGNAL	1 Red	+24V	6 Green	DIM+
RED	+24V	GREEN	DIM+	2 Black	-24V	7 Yellow	DIM-
BLACK	-24V	YELLOW	DIM-	3 Blue	NMEA IN+	8 Grey	DIMKEY
BLUE	NMEA IN+	GREY	DIMKEY	4 White	NMEA IN/OUT-	DIM+	DIM930
WHITE	NMEA IN/OUT-	DIM+ 	REMOTE DIMMER	5 Orange	NMEA OUT+	DIM-	DIMMER
ORANGE	NMEA OUT+	DIM-				DIMKEY	

Environmental according to IEC60945

Supply voltage: 24V DC (10-32V)

Power consumption: 3W at 24V


Operating temperature: **-15- +55 degree C according to IEC60945**

To increase life-time, we suggest working temperature to be held at 0 ~ +40 degrees C.

Storage temperature: -20 - +70 degree C

Humidity: 10 - 90% relative, no condensation.

IR861 installation



The unit can be mounted in panel, table, wall or ceiling.

1. For tabletop mounting, wall or ceiling mounting use the supplied bracket.
2. For panel (flush) mounting, take off the bracket and take off the front frame. Cut a 125x125mm Din size square window in the panel, fix the inside 4 holes with tapping screws, and put on the front frame again.