




K 4 Premium Full Control Home

The K 4 Premium Full Control Home comes with a five year warranty. The addition of a hose reel and the home kit make cleaning around your home easier than ever.

MISSING
PIC-
TURE: D:\
IM0027641





1 Full Control trigger gun and spray lances

- Gives you direct feedback as to the pressure setting you are on, ensuring you get the right pressure setting for the surface you are trying to clean.
- The pressure can be regulated by twisting the Vario Power spray lance until the desired level is shown.


2 Parking position for easy accessory storage at all times

- The Full Control trigger gun and the connected spray lance can be stored on the pressure washer during cleaning.
- The Full Control trigger gun is easily accessible.



3 Plug and Clean

- Quick and easy application of detergents through the pressure washer, when in detergent mode.
- Kärcher detergents increase efficiency while cleaning, help prevent dirt from returning and help to protect and care for your surface.



4 Hose reel

- The high-pressure hose can be quickly and easily wound onto the hose reel, helping provide a simple storage solution.



K 4 Premium Full Control Home

- Full Control Trigger Gun with pressure setting display
- Maximum stability thanks to low centre of gravity, hose guide and a larger base
- Highly efficient water-cooled motor

Technical data

Order Number		1.324-105.0
EAN code		4054278130835
Pressure	bar / MPa	20-130 / 2-13
Flow rate	l/h	420
Max. water feed temperature	°C	max. 40
Power rating	kW	1,8
Weight without accessories	kg	11,9
Dimensions (L x W x H)	mm	411 x 305 x 584
Current type	V / Hz	230 / 50

Equipment

High-pressure gun	G 145 Q Full Control	Telescopic handle	■
Vario Power spray lance	■	Water-cooled motor	■
Dirt Blaster spray lance	■	Soft bag	■
High-pressure hose	m	6	
Quick Connect on machine	■		
Detergent application via	Plug and Clean system		
	■		
Integrated water filter	■		
Adapter garden hose A3/4"	■		
Home kit	T350 Patio Cleaner, 1 L 3-in-1 Stone and Facade Detergent		
High-pressure hose reel	■		

■ Included in delivery.

K 4 PREMIUM FULL CONTROL HOME

1.324-105.0

KÄRCHER


		Order Number						Price	Description	
Hard surface cleaners										
T350 Patio Cleaner	1	2.643-252.0							The Kärcher T350 patio cleaner allows you to clean large areas quickly and efficiently, as well as being splash-free. This model includes adjustable cleaning pressure for different surfaces.	■
Spare nozzles accessories T 300 / T 350	2	2.643-335.0								□
T450 Patio Cleaner	3	2.643-214.0							The T450 Kärcher patio cleaner is a handy attachment for your Kärcher pressure washer. Twin-jet rotating arms allow you to clean areas like patios and decking faster and with great results.	□
PS 40 Power Scrubber	4	2.643-245.0							The Kärcher PS40 power scrubber comes with three integrated high-pressure nozzles giving you a powerful, reliable and time-saving solution for removing stubborn dirt on a variety of surfaces.	□
T550 Patio Cleaner	5	2.643-251.0							The Kärcher T550 patio cleaner is our most powerful patio cleaner. Allowing you to clean large surface areas quickly. Included in this model is a detergent application feature.	□
Spare nozzles accessories	6	2.643-338.0							High-quality replacement nozzles for all T-Racer surface cleaners (except T 350) for unit classes K 2 to K 7, gutter cleaner PC 20 for K 3 to K 7, as well as chassis cleaner for K 2 to K 5.	□
Spray lances										
Full Control Vario Power Jet for K4 - K5, VP145	7	2.642-725.0							This spray lance is continuously adjustable from low-pressure detergent jet to high-pressure jet, simply by turning the spray lance. Suitable for use with K4 - K5 power washers.	■
Full Control Dirt Blaster for K4 - K5, DB145	8	2.642-728.0							The Dirt Blaster for power washers in the K4 - K5 range. This spray lance is suitable for use on particularly stubborn dirt like mossy pavements or house walls.	■
Telescopic jet pipe	9	2.642-347.0							The Kärcher Telescopic jet pipe allows for easy cleaning of difficult to reach areas. With a shoulder strap and an ergonomically adjustable trigger gun, allowing you to reach up to 4m.	□
Splash guard	10	2.642-706.0							The transparent splash guard for K2 to K7 Kärcher pressure washers protects you and the surrounding area from spray water. Ideal for cleaning corners and edges.	□
Angled spray lance	11	2.638-817.0							Extra-long angled spray lance (about 1 m) for easy cleaning of difficult to reach areas, e.g. roof gutters or vehicle underbodies.	□
Single Lance Extension	12	2.643-240.0							Extends spray lance by 0.5 m. For effective cleaning of difficult to reach areas. Suitable for all Kärcher accessories.	□
Mini VP160 Vario Power Jet	13	2.643-254.0							The Kärcher Mini Vario Power Jet comes with infinite pressure regulation and an adjustable 360° joint, ideal for cleaning difficult to reach areas. For use with K2 - K7 pressure washers.	□
MP 145 Multi Power Jet	14	2.643-239.0							The Kärcher multi-power jet has 5 different types of jets: Cleaning agent jet, High Pressure fan jet, rotary nozzle, pencil jet and wide reduced-pressure fan jet.	□
Trigger guns										
Full Control Trigger Gun	15	2.643-634.0							New Full Control trigger gun comes with an LED display to guide you to the correct pressure setting for the surface you are trying to clean. Helping you achieve the best results for your home.	■

■ Included in delivery. □ Available accessories.

K 4 PREMIUM FULL CONTROL HOME

1.324-105.0

KÄRCHER


		Order Number						Price	Description	
Brushes										
WB 150 power brush	16	2.643-237.0							The Kärcher WB150 pressure washer brush is the perfect attachment for cleaning delicate surfaces such as car exteriors, motorbikes, glass, garage doors and conservatories.	<input type="checkbox"/>
WB 120	17	2.644-060.0								<input type="checkbox"/>
WB 120 Car & Bike	18	2.644-129.0								<input type="checkbox"/>
WB60 Soft Surface Wash Brush	19	2.643-233.0							The Kärcher WB60 soft wash brush is a great addition to your Kärcher pressure washer to help you clean larger surfaces like cars, caravans, boats and conservatories.	<input type="checkbox"/>
Wheel Washing Brush	20	2.643-234.0							The Kärcher wheel washing brush is perfect for removing dirt and grime that accumulates on your wheel rims. With 360° degree cleaning enabling you to reach every angle of your wheels.	<input type="checkbox"/>
Adapter for garden hose connection	21	2.640-732.0								<input type="checkbox"/>
WB100 Rotating Wash Brush	22	2.643-236.0							The Kärcher WB100 rotating wash brush is ideal for cleaning all smooth surfaces like paint, glass or plastic. It comes with a 180° joint making it infinitely adjustable.	<input type="checkbox"/>
High-pressure hose extension - System from 2008										
High-pressure extension hose, 10 m, K2 - K7 (for gun model "Best").	23	2.641-710.0							High-pressure extension hose for greater flexibility. 10 m robust DN 8 quality hose for durability. For K2 - K7 series from 2008 with Quick Connect connector.	<input type="checkbox"/>
High-pressure extension hose, 6 m, K3 - K7 (for gun model "Best").	24	2.641-709.0							High-pressure extension hose for greater flexibility. 6 m robust DN 8 quality hose for durability. For K2 - K7 series from 2008 with Quick Connect connector.	<input type="checkbox"/>
High-pressure extension hose, 10m	25	2.641-708.0							The Kärcher high-pressure extension hose gives you greater flexibility. The 10m high-quality hose is steel reinforced for durability. Compatible with K3 - K7 pressure washers.	<input type="checkbox"/>
Pipe cleaning										
Roof gutter and pipe cleaning set	26	2.642-240.0							The Kärcher roof gutter and pipe cleaning kit is an effective way to clean and remove blockages in pipes, drains, downpipes and toilets. Compatible with all Kärcher pressure washers.	<input type="checkbox"/>
Pipe cleaning set, 15 m	27	2.637-767.0							Pipe cleaning set with 15 m hose for clearing blockages in pipes, drains, downpipes and toilets.	<input type="checkbox"/>
Pipe cleaning set, 7.5 m	28	2.637-729.0							Pipe cleaning set with 7.5 m hose for clearing blockages in pipes, drains, downpipes and toilets.	<input type="checkbox"/>
Foam jet										
FJ 6 foam nozzle	29	2.643-147.0							The Kärcher FJ6 foam nozzle is the perfect addition to your Kärcher pressure washer, allowing you to add a layer of foamy detergent with the minimum of effort and fuss.	<input type="checkbox"/>
Foam nozzle Connect 'n' Clean FJ10 C Ultra Foam Cleaner 1L	30	2.643-143.0							The Kärcher Ultra Foam Detergent & FJ10 C Connect 'n' Clean foam nozzle is the most effective way to apply detergent. Allowing you to switch between detergents for different tasks.	<input type="checkbox"/>
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Car Shampoo	31	2.643-144.0							Car Shampoo & FJ 10 C Connect 'n' Clean foam nozzle - The most effective way to apply detergent. Also allows a simple switch between different detergents for different tasks.	<input type="checkbox"/>
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Stone Cleaner	32	2.643-145.0							3in1 Stone cleaner & FJ 10 C Connect 'n' Clean foam nozzle - The most effective way to apply detergent. Also allows a simple switch between different detergents for different tasks.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.

K 4 PREMIUM FULL CONTROL HOME

1.324-105.0

KÄRCHER



		Order Number					Price	Description	
Miscellaneous									
Suction hose SH 5	33	2.643-100.0						Eco-friendly 5 metre suction hose for drawing water from alternative sources such as water butts and barrels.	<input type="checkbox"/>
Sand/wet blasting set	34	2.638-792.0						Sand and wet blasting set for removing rust, paint and stubborn dirt using Kärcher abrasive.	<input type="checkbox"/>
Vario joint	35	2.640-733.0						Vario joint, rotates 180° for cleaning difficult to reach areas. Connection: For connection between gun and accessory or extension lance and accessory.	<input type="checkbox"/>
Water filter	36	4.730-059.0						Water filter protects pressure washer pumps against dirt particles from dirty water.	<input type="checkbox"/>
Replacement O-ring set	37	2.640-729.0							<input type="checkbox"/>
Kärcher organiser	38	2.641-630.0						Kärcher organiser, the practical wall-mounted storage system for Kärcher accessories. With two modules for flexible mounting. Ideal for protecting wash brushes and bristles from bending.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.

K 4 PREMIUM FULL CONTROL HOME 1.324-105.0

KÄRCHER



		Order Number						Price	Description	
Hose Storage and Hose Trolley										
Premium Hose Reel HR 7.315 Kit 5/8"	1	2.645-165.0								<input type="checkbox"/>
Premium Hose Reel HR 7.315 Kit 1/2"	2	2.645-164.0								<input type="checkbox"/>
Hoses										
Connection Set for high-pressure cleaners	3	2.645-156.0								<input type="checkbox"/>
Indoor Hose Connection Set	4	2.645-258.0								<input type="checkbox"/>
PrimoFlex® Hose: 1/2" - 20m	5	2.645-138.0								<input type="checkbox"/>
PrimoFlex® hose 3/4" - 25 m	6	2.645-142.0								<input type="checkbox"/>
Hose Performance Plus 1/2" - 20m	7	2.645-318.0								<input type="checkbox"/>
Hose Performance Plus 3/4" - 25m	8	2.645-322.0								<input type="checkbox"/>
Performance Premium hose, 1/2" - 20 m	9	2.645-324.0								<input type="checkbox"/>
Connectors/Tap adaptors										
Universal hose coupling Plus	10	2.645-193.0							Universal hose coupling plus with soft plastic recessed grips for comfortable handling. Compatible with all click systems.	<input type="checkbox"/>
Universal hose coupling Plus with Aqua Stop	11	2.645-194.0							Universal hose coupling plus with Aqua Stop and soft plastic recessed grips for comfortable handling. Compatible with all click systems.	<input type="checkbox"/>
Universal hose coupling with Aqua Stop	12	2.645-192.0								<input type="checkbox"/>
Universal hose coupling	13	2.645-191.0								<input type="checkbox"/>

■ Included in delivery. □ Available accessories.